

Cleaning Matrix - DTP 25®

| Part | Frequency | | | | | | | |
|---|--------------------------|---------------------|----------------------|---|---------------------|---------------------|---------------------------|-----------------------------|
| | After installing machine | After every use | Before every use | In between products that present a cross contamination risk | Weekly | Monthly | Before placing In storage | After removing from storage |
| Ejection Tray | Remove from machine | Remove from machine | Install on machine | Remove from machine | N/A | N/A | Remove from machine | Install on machine |
| Tooling | Remove from machine | Remove from machine | Install into machine | Remove from machine | N/A | N/A | Remove from machine | Install on machine |
| Boot | Remove from machine | Remove from machine | Install into machine | Remove from machine | N/A | N/A | Remove from machine | Install on machine |
| Base Plate | Remove from machine | Remove from machine | Install on machine | Remove from machine | N/A | N/A | Remove from machine | Install on machine |
| Hopper | Remove from machine | Remove from machine | Install on machine | Remove from machine | N/A | N/A | Remove from machine | Install on machine |
| Top Cam area | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine |
| Upper Drift Pin Assembly | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine |
| Motor | Clean on machine | Clean in machine | Clean in machine | N/A | Clean on machine | Clean in machine | Clean on machine | Clean on machine |
| Upper Drift Pin Assembly Mounting Block | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine |
| Upper Drift Pin Assembly Threaded Cam | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine | Clean in machine |
| Lower Drift Pin Assembly | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine | Remove from machine |
| Perspex Base | Clean on machine | Clean in machine | Clean on machine | Clean on machine | N/A | N/A | Clean in machine | Clean on machine |
| Base/Frame | Clean on machine | Clean in machine | Remove from machine | Remove from machine | N/A | N/A | Clean in machine | Clean on machine |

Cleaning Level Key

Level 1 - Remove powder

Level 2 - Dry clean with cloth

Level 3 - Dry clean and re-lubricate if specified in lubrication schedule

Level 4 - Wet clean and re-lubricate if specified in lubrication schedule

Remove from machine - Take part out of machine and clean if required. Store it correctly or install back into machine.

Install into machine - Install part into the machine and make sure that it has been cleaned. If needed, lubricate to the level required.

Clean on/in machine - Clean the part while in the machine and do not remove it. Make sure that all contact surfaces are clean to the level required.

This cleaning matrix is intended as a guide only and is not an exhaustive list. All cleaning schedules will need to be adapted to the industry and product, following industry regulations and the material safety data sheets that come with specific products. Please check with your Food Safety Manager/Department, Quality Control Manager/Department, or other relevant internal departments at your company before using.